Combi

Combi Baby Label Cooking set

User manual

For safety of your baby, please read this manual carefully and use accordingly. Please keep this manual properly for future reference. If you transfer the product to others, please also attach this manual to the product.



Combi Corporation

| Index | | | | | |
|--|--------------------|--|--|--|--|
| Before use1 | Applicable age6 | | | | |
| For safety1~3 | Storage after use7 | | | | |
| ● When using2 | Materials7 | | | | |
| Caution items about use with | How to use8~10 | | | | |
| microwave oven3 | | | | | |
| Washing and sterilizing4 | | | | | |
| Name of parts | | | | | |

Before use

- This product is a general tableware set to be used to feed child with weaning food etc..
- Before use, wash the tableware set thoroughly.

For safe use of our product

● The caution items mentioned in this user manual are for your reference in order to use this product safely. [Warning] and [Caution] indicate the potential consequences if the mentioned are not followed properly and are categorized according to the level of severity.

| <u></u> MARNING | Improper usage may result in death or severe injury. |
|------------------------|---|
| ∴ CAUTION | Improper usage may result in injury or damage to product. |

Caution items about use with microwave oven

⚠ CAUTION

- Strainer plate and cutting plate are made with metal so please do not place them into microwave oven.
- Plastic part may be damaged if the below is not followed properly. Make sure to follow the below accordingly.
- Make sure not to apply this product to direct heat source, hot plate, oven, griller or toaster etc..
- After using of griller or toaster as in the microwave oven, make sure the temperature inside is not high before place the product
- Do not expose empty tableware to heat source.
- Do not heat any tableware that is tightly air-sealed.
- Do not use with food with high oil or sugar content since they may become very hot upon heating.
- When using to heat food with little water content, make sure to set the microwave oven timer to a short period of time and watch carefully.

Use only within the temperature guidelines indicated on the product.

Follow the below properly to avoid getting burnt.

Make sure to follow the below accordingly.

- Tableware may become very hot upon heating. When taking out from microwave oven pay particular attention.
- When using the masher (of the compact cooking set with mini colander) as a lid in the microwave oven, pay attention in case hot steam may come out accidentally.
- Color from food like carrot, tomato or pumpkin may stain onto the tableware
- Food may burst out when heating with microwave oven. Do not overload the tableware with food or liquid.
- Make sure to follow the instructions of the microwave oven as well
- Take extra care when microwave heating. Always stir heated food to ensure even heat distribution and test the temperature before

3

When using

⚠ WARNING

For your child's safety and health

- Always use this product with adult supervision.
- Before each use, inspect the product, Throw away at the first sign of damage or weakness.
- Always check food temperature before feeding.
- ●When using the product in microwave oven, in case the liquid inside may cause boiling phenomenon (%) and burst, wait for 1 minute or more before taking the tableware from the oven.

*Boiling phenomenon refers to the effect of overheated liquid when liquid suddenly boils vigorously upon a sudden movement.





⚠ CAUTION


- Do not allow child to play as toys
- Keep products away from child's access.
- Be careful when handing the cookware to avoid any accidents.
- Do not drop or expose product to shock. Damage may be caused.
- If any of the items appear to cause an allergic reaction to the baby's skin, cease using and consult a doctor immediately.

2

Washing and sterilizing

- Make sure to wash thoroughly before and after use of product.
- Do not apply abrasive washing powder or scrubbing brush as they may hurt the product surface. Use soft sponge to wash the product.
- Apply neutral detergent only when washing, Follow the instructions of the detergent.
- When sterilizing, use a large pot and pour enough water inside and heat the water up until it boils. Place tableware inside for around 2~3 minutes. (Exposure to boiling water for too long may cause damage
- When bleaching the product, apply bleaching agents that are suitable to kitchenware
- Do not bleach for more than 30~40 minutes. Follow the bleaching agent instructions properly.
- When using sterilizing agent or anti-bacteria agent, make sure to follow the caution items accordingly.
- When using dish washer, make sure to follow the instruction properly.
- Food color may remain on the product surface even after washing. This does not affect normal use of product.

Name of parts



Applicable age

| Age | 5 mor | nths 7 mg | onths 9 m | onths 12 i | nonths |
|----------------|----------|------------|-----------|------------|--------|
| | | To swallow | To mumble | To chew | To eat |
| Strainer plate | • | | | | |
| | 000 | | 00000 | 00000000 | 0000 |
| Grater plate | • | | | | |
| | | 00 | | 0000000 | 0000 |
| Cutting plate |) | | | | |
| Mortar | | | | | |
| Mortal | | | | | |
| | | | | | |
| | <i>J</i> | | | | |

- Please use according to different growth stages of child.
- •Use together with necessary cooking tools like knives etc..

6

Storage after use

- After use, apply neutral detergent and wash the tableware immediately with warm water.
- ●If any damage or rift is found on product, stop using immediately and replace with new ones.
- ●The components can be stacked and stored together.



Material:

| Item | Plastic Resign Material | Heat Resistance | Cold Resistance | Volume |
|----------------------------------|----------------------------|--------------------|--------------------|--------|
| ●Mortar | Polypropylene | 140°C | -40°C | 330ml |
| ■ Mash bowl | Polypropylene | 140°C | -40°C | 280ml |
| Strainer plate | | | | |
| Frame | ABS | 100°C | | |
| Net | Stainless steel | 100°C | | |
| Grater plate | Polypropylene | 140°C | | |
| Cutting plate | | | | |
| Frame | ABS | 100°C | | |
| Net | Stainless steel | 100°C | | |
| ● Lid for | | 140°C | -40°C | |
| microware oven | Polypropylene | 140°C | | |
| ● Spatula | Polypropylene | | | |
| | | | | |

7

10

How to use

- Size of each plate is designed to fit in different stages.
- Cooking set has different functions like strainer, grater, cutter or grinding etc..

5

- Cooking set can be used together with microwave oven for simple
- Components can be stacked together for easier storage.
- Spatula included.



• Set the cutting plate onto the mash bowl or mortar and then use the spatula to gradually press the cooked vegetable etc. through the cutting plate, either through the 5mm or 10mm blade.





5 Spatula

•Just right thickness to fit your hand and be used in way ①~④



All stage



Strainer plate (Not designed for microwave)

- Set the strainer plate onto the mash bowl or mortar, and then use the spatula to gradually strain out the cooked vegetable etc..
- ●Food paste for weaning stage is then made easily.




Grater (7-8 months)

4 Mortar (white) or mash bowl (yellow)

(Microwave-safe) ●Use the spatula to grind the

- cooked food you want. ●You can also put meat or fish inside to prepare food paste.
- ●Can be used in combination with other plate items.
- •Microwave-safe and can be used as a normal tableware.





6 Lid for microwave (Microwave-safe)

- ●Can be set onto the mash bowl or mortar and used in microwave.
- ●Can be used as a lid for storage.



Lid / Storge All stage

Grater plate (Microwave-safe)

- •Set the grater plate onto the mash bowl or mortar and then grate the vegetable or fruits gradually using the grater plate.
- ●Grate plate has different grating sizes, one on each

