


auto N Neo

Instruction Manual



IMPORTANT – READ CAREFULLY AND KEEP FOR FUTURE REFERENCE.




Using safety harness

1. Buckle: When you hear a "click" sound, the safety harness is securely buckled.
2. Length adjustment of safety harness Lengthen:
To loosen it: While holding the slide buckle, pull to loosen the belt in the direction of b, and then adjust the upper and lower shoulder belts to the same length.
To fasten it: While holding the slide buckle, pull to tighten the belt in the direction of a, and then adjust the upper and lower shoulder belts to the same length.

Note: For the safety of children, please make sure that the safety harness is securely buckled when using the stroller.



Safety lock



Front guard

Front guard: Adjust the slider with a protruding square button on the front guard plug to align with the square hole of the front guard socket on the stroller and insert it until you hear a "click" sound. The front guard is detachable on both sides.



Note:

1. When installing the front guard, please aim the front guard button at the front guard seat to avoid incorrect assembly, and pay attention to the installation method to avoid pinching.
2. When using the stroller, please pay close attention to the gap of the position marked with dotted lines in the figure to prevent the child's hands and feet from getting stuck accidentally.



Seat Extension

Press the button on both sides of arrow with hands to adjust the seat extension.






Canopy

Open the zipper can enlarge the canopy.



Backrest



1. Release the safety buckle.
2. From behind the seat base, rotate the end buckle of the lap belt vertically, then slowly pull the left and right lap belts out from the waist area.
3. Put the left and right buckles vertically through the belt holes on the inner seat and the base seat's .
4. Remove the left and right inner seat straps from the base seat's holes.



Backrest


Adjusting the Backrest Angle:

1. As shown in the illustration, to adjust the backrest, pull the adjustment straps upwards or downwards with both hands to tighten the seat to your desired angle. Secure the position using the Velcro strap.
2. As shown in the illustration, the rear flap can be opened at any time for monitoring or ventilation. Once opened, attach the magnetic snaps on both sides directly to the backrest frame to keep it in place.



Wheel function

For easy cleaning and storage, the front and rear wheels support the quick release function.



1. Please wipe away any dirt or grime from the lubrication points before applying lubricant. If excessive lubricant is used, dust may adhere to the lubricated components, it will reduce their functionality.
2. When installing the rear wheel, insert the bearing inward and pull the wheel to ensure the installation is complete.

CAUTION

Do not allow oil to come into contact with the front guard or any other areas that children might lick.

The stopper

WARNING

Always engage the stopper when you leave the stroller.




Opening the stroller

1. Lift the handle backward and upward to unfold the stroller. Shake the handle up and down to confirm that the stroller is fully unfolded and locked.
2. Pull the seat in the direction of the arrow and press the pedal adjustment button with both hands to adjust the pedal.

Note: When unfolding the stroller, please pay attention to the installation methods to avoid pinching.

⚠ WARNING

When opening or folding the stroller, ensure infants and toddlers are safety distance from the stroller's moving parts. Operators must not touch folding mechanisms such as dotted-line loops to avoid pinching injuries.




Folding the stroller

1. Close the canopy and adjust the seat as lowest position or parallel of handle.
2. Release the safety lock.
3. Stroller will auto fold.

Tips : If the seat angle is raised to its highest position, it may prevent the seat from folding automatically. If the seat fails to auto fold, please adjust the seat angle to its lowest position and fold it.

⚠ WARNING

- Any wrappings such as coverings and cable ties should be removed or kept away from children.
- When unfolding / folding the stroller, it must be made clear that the infant's limbs are kept at a safe distance from the trolley. And the operator should not touch the folding mechanism such as the dotted coil to avoid pinching.
- When opening the stroller, please make sure you hear a "click" locking sound and lift the handle up to check that it is fully locked.
- Never allow the harness tightening strap to become caught in moving parts (e.g. automatic doors, escalators, etc.).
- When the stroller is in use, the portable shoulder strap cord should be removed and not kept in the sitting area, away from the child.



⚠ WARNING (Incorrect operation may cause serious injury or death)

The safety of the child may be seriously endangered if the instructions are not followed. You are personally responsible for the safety of your child.

- The stroller is suitable for children from birth to 4 years or up to 22kg, whichever comes first.
- Comply EN 1888-2:2018+A1:2022 safety standard.
- Never leave the child unattended.
- The vehicle is designed for only one child use.
- The stroller is not allowed to carry two or more children or other items at the same time.
- Check that the pram body or seat unit or car seat attachment devices are correctly engaged before use.
- Overloading, incorrect folding and the use of non-approved accessories may damage this stroller.
- Before use, make sure that the stroller stands upright and all mechanisms are fixed to ensure safety.
- To avoid injury ensure that the child is kept away when unfolding and folding this product.
- Do not let the child play with this product.
- Always use the restraint system to avoid any possible accident.
- The safety harness or restraint system must be correctly buckled and used.
- When adjusting any movable parts on the stroller, keep a safe distance between the child's limbs and the stroller.
- The child may slip into gaps near the sole of its feet, which may cause suffocation.
- Do not use the stroller on stairs.
- Do not place the stroller near fire, high temperature, pool, or electric source.
- Do not allow your child to stand in or on the stroller, it may be dangerous.
- Do not leave the stroller on roads, ramps or any other dangerous places.
- Do not lift stroller while child is in stroller.
- Do not move the stroller by holding the seat.
- Be sure to use all braking devices when parking the stroller.
- To prevent accidents, ensure that the stroller is kept away from any automatically closing doors (for example, doors of train or elevator).
- To avoid the risk of suffocation, any coverings and binding straps must be removed, destroyed or kept away from the child.
- This product is designed for walking use only.
- This product is not suitable for running or skating.
- Ensure that all the locking devices are engaged before use.
- Excessive weight may cause a hazardous and unstable condition exist. (Maximum load: 22kg. Basket maximum load: 5kg).
- When adjusting the seat angle with a child seated in the stroller, please readjust the safety harness to a proper length. Do not adjust the seat angle while you are moving the stroller. Do not suddenly change the seat angle.
- If one gives excessive shock to the front wheels when getting over the step, stroller may fall down and cause damages. When stepping over, such as a curb, please slow down even a slight difference level, pull downward the handle and step on the foot-step, and make sure to pass the front wheels to get over the step.
- Lift front wheels and pay particular attention to gaps or ditch when crossing rail road to avoid the front wheels from accidentally getting to jammed and tipping over.
- Do not use in a reclined angle less than 150° for a child under 6 months old. when a child under 6 months old, please use of the most reclined position.
- Any loading attached to the handle affects the stability of the stroller, on the back of the backrest and/or on the sides of stroller will affect the stability of the stroller.
- Only replacement parts supplied or recommended by the manufacturer/ distributor shall be used. Only use original accessories and parts that have been approved by the manufacturer. Do not make any modifications to the product.
- The parking device shall be engaged when placing and removing the children or stop the stroller, in case of sudden brake or turning, and then the stroller may fall off.
- Do not place toys or things with straps attached around the children riding around in a baby carriage.
- Check regularly that all screws, bolts and nuts are engaged tightly.
- In the event of damage or operation problems, stop using the stroller immediately and keep it out of reach of children.
- Make sure that there is no foreign matter adhering to the magnet buckle.
- When fastening the seat belt, be careful not to pinch the child's limbs, clothing, or foreign objects.

Maintenance and Cleaning

- Never apply force on any mechanism or moving parts.
- To prevent mildew forming, do not store this product in a wet or humid environment.
- Avoid prolonged exposure of the product to rain or snow.
- Clean with a wet cloth. For stubborn stains, use a diluted mild detergent.
- After wipe off the dirt by detergent, use a cloth to wipe off the excess water and detergent.
- Dry in shade area after wipe off water.
- You may lubricate moving parts if the Wheel turning part of the stroller is not smooth. Please do not apply any lubricating oil other part that will cause malfunction. Please do not apply any lubricating oil other part that will cause malfunction.
- In the event of if you find the tyre wear seriously affect movement/ stroller damage or operation problems, please contact customer service center.

Hong Kong and South East Asia countries



For more information, you can scan this QR code.

Hong Kong and South East Asia countries, please contact below :

Supplier: Combi Hong Kong Limited
Address: Units 1616-18, 16/F, Tower 1, Grand Century Place, 193 Prince Edward Road West, Mongkok, Kowloon, Hong Kong

Combi Corporation