Combi

SUGOCAL Switch Plus



EN

Instruction manual

繁體中文

說明書

IMPORTANT: KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE.

WARNING (Incorrect operation may cause serious injury or death)

Please read this instruction manual carefully and keep it for future reference. The safety of the child may be seriously endangered if the instructions are not followed. You are personally responsible for the safety of your child.

- The stroller is suitable for children from newborn 1 month to 18kg.
- · Always apply the parking brake when you are stationary.
- Do not rely too much on the stopper even when the stroller is parked empty.
- · Even with all stopper engaged, always stay close to the stroller when it is carrying a child.
- Keep all small parts away from children as they are choking hazard.
- To prevent the risk of suffocation, always keep the plastic bags out of the reach of children.
- Overloading, incorrect folding and the use of non-approved accessories such as buggy boards may damage or break this stroller.
- Make sure to use the seat belt (crotch belt, waist belt and shoulder belt) when the child is seated. The front guard is not designed to prevent the child from standing up. Check if the seat belt fits properly, otherwise the baby may fall off from the stroller.
- Pay attention to child even when seat belt is in use in case of any sudden movement of child causing it to fall off.
- Do not cross the shoulder belts with each other when securing the shoulder belts to the insert plastic. Otherwise excessive pressure may be caused to child's neck.
- Do not use the seat cushion on which rift is found. Otherwise the seat cushion may not function as designed or the child may have chance to swallow the material inside the cushion.
- Seat cushion can play a protective role. When the stroller is not installed with a seat cushion, please stop using the stroller. Otherwise, there may be risk of injury.
- Do not leave the stroller when the child is seated.
- Make sure the open-fold lock is engaged completely before use. Otherwise the stroller may fold suddenly in use.
- Do not let the child operate the front guard. It may make the child to fall off from the stroller.
- Do not allow your child to stand in or on the stroller, it may be dangerous.
- · Do not lean on or hang loads on the handle.
- Do not hang parcels or accessory items (except Combi original accessories) on the stroller, otherwise tipping over may happen to stroller.
- Never carry more than one child in the stroller. Do not allow a child to ride or sit on any area other than the seat.
- Excessive weight may cause a hazardous unstable condition exist. (Maximum load:18kg. Basket maximum load:5kg)
- · Do not use the stroller on stairs.
- Do not let children operate the baby stroller to avoid tipping over or accident.
- Be careful of those around you to avoid pinching their fingers when you are opening or folding the stroller or adjusting the seat angle.

IMPORTANT: KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE.

WARNING (Incorrect operation may cause serious injury or death)

- Keep your child's fingers/hands away from moving/folding parts when folding or unfolding or adjusting the stroller.
- Do not apply a lifted seat to baby who cannot sit straight by itself, the most reclined position is recommended for newborns.
- When pushing the stroller, please walk slowly to avoid any damage to the stroller swivel wheels or any tipping over.
- Open the baby stroller in clear area to avoid pinching baby's finger.
- The used insert outlet from base seat and the cushion should be matched. (e.g. upper insert outlet of base seat should match with upper insert outlet of cushion). Otherwise, the shoulder belt may not be long enough to harness the baby.
- It is extremely dangerous to adjust the seat angle when pushing the stroller. Do stop the stroller first before operation.
- Mind the road when move the stroller and prevent any wheel get stuck in the gap of the drainage ditch cover(s).
- Child may slip into leg openings and strangle. Never use in reclined carriage position(s)
 unless the ASTM-footcover is attached.
- Never leave the child unattended. It may be dangerous to leave your child unattended.
- Ensure that all the locking devices are engaged before use. Such as adjust your seat belt length, fasten your seat belt correctly and the stroller is fully opened.
- · Always use the restraint system to avoid any possible accident.
- Do not use in a reclined angle less than 150° for a child under 6 months old.
- Any loading attached to the handle affects the stability of the stroller.
- Please always fasten the five-point seat belt to ensure the baby's safety.
- This product is not suitable for running or skating.
- Do not let the child play with this product.
- To avoid injury ensure that your child is kept away when unfolding and folding this product.
- Do not place the stroller near fire, high temperature, pool, or electric source.
- Only replacement parts supplied or recommended by the manufacturer/distributor shall be used. Only use original accessories and parts that have been approved by the manufacturer. Do not make any modifications to the product.

CAUTION (Incorrect operation may cause injury or component damage)

- Make sure all snaps are secured when attach the seat cushion to stroller. Otherwise accident or damage to stroller may happen.
- Loose the shoulder belts and support the backrest with the other hand before lowering
 the seat angle with a child seated. Do not suddenly change the seat angle while a child
 is seated.
- Adjust the length of seat belt properly after change of the backrest angle.
- Please do not touch the folding lever except when folding the stroller.
- When opening or folding up the stroller, be careful and avoid the seat cushion, seat belt, blanket and toys, etc., being pinched into the stroller body.
- If one gives excessive shock to the front wheels when getting over the step, stroller may fall down and cause damages. When stepping over, such as a curb, please slow down even a slight difference level, pull downward the handle and step on the foot-step, and make sure to pass the front wheels to get over the step.
- Never lift the stroller or use it on escalators or stairs when your child is sitting or lying in the stroller.
- This stroller requires regular maintenance by the user.
- Before use, check that the product and all its components have not been damaged during transportation.
- Please do not use the stroller in whatever purposes other than seating a baby. Failure to comply may result in damage of the stroller.
- Do not pull or twist or forcibly press down the front guard hardly. Otherwise the stroller may be damaged.
- Lift the backrest a little to use if the seat is found too narrow when fully reclined. However, the baby should be able to sit straight when stroller is used in such way.
- Do not let an adult sit on the stroller, or add loading on the stroller to avoid any damage to it.
- Avoid continuous outdoor usage particularly during day time in summer.
- Avoid storing the stroller in save places under high temperature, near a heat source or inside a car. Exposure to high temperature may damage or deform the stroller.
- Check regularly that all screws, bolts and nuts are engaged tightly.
- · For use on trains:
 - This product is not designed to be used on trains. When user attempts to use the product at his /her own risk, please lock stopper in case of sudden brake or turning. Otherwise stroller may fall off.
- Do not press on the folding lever while lift the stroller to avoid damage to the part.
- Make sure the basket is empty before folding up the stroller.
- Make sure the canopy is completely folded up before folding the stroller to avoid damage of the parts.
- Do not lay down the stroller and do not put things on the canopy to avoid deformation.

CAUTION (Incorrect operation may cause injury or component damage)

- Do not get hold of an opened front guard to pull the baby stroller.
- Even have stopper, this stroller may also be accidental slip or overturned.
- Do not leave baby stroller at road side or slope even when it is not in use.
- Do not use the stroller on steep slopes, stairs, escalators, rough roads, beaches, mud, etc.
- When pushing the stroller, please pay attention to any hole or track on the ground to avoid the front wheel from accidentally getting jammed and tipping over.
- In the event of damage or operation problems, stop using the stroller immediately and keep it out of reach of children.
- · Never leave the stroller close to stairs or steps.
- In the event of damage or operation problems, please contact customer service center (or local distributor).
- Only use on a flat, relatively smooth, stable and non-slippery surface. Do not use the stroller in snowy, windy days or wet road to avoid the stroller or guardian from slipping.
- Do not use the stroller in lightning days to avoid thunder stroke.
- Do not attach other accessory like buggy board on the main body during a child being carried in stroller, otherwise accident or damage to stroller may happen.
- Do not use the stroller on public vehicles.
- Lift front wheels and pay particular attention to gaps or ditch when crossing rail road to avoid the front wheels from accidentally getting to jammed and tipping over.
- No continuous use for a long period: Continuous use for a long period of time may exhaust baby. No continuous use of more than 2 hours for a baby in a reclined seat and 1 hour in an upright seat.
- When feel jammed, please do not forcibly fold the stroller to prevent from any damage. You should reopen the stroller to check and operate again.
- Turn swivel wheels to inner side and lock up before folding the stroller. Improper position may cause stroller becoming imbalanced after folded.
- Do not put things that are too sharp or too large into the basket since it may cause damage to the basket.
- Please regular cleaning and checking the stroller. Only use neutral detergent to clean the stroller body.
- Make sure no oil or lubricant is left on parts such as front guard or armrest where baby may have chance to lick.
- Please contact customer service center (or local distributor) for replacement if you find the tyre wear seriously affect movement.
- Parking device shall be engaged when placing and removing the children.
- Any load attached to the handle and/or on the back of the backrest and/or on the sides of stroller will affect the stability of the stroller.
- Fasten the safety belt securely, but do not have it too tight.
- Do not hold the front guard to lift the stroller while a child seated. Failure to comply may cause the stroller to fold up suddenly, release the front guard accidentally, or cause the

⚠ CAUTION (Incorrect operation may cause injury or component damage)
stroller to slip off. • When traveling on vehicles such as subways / high-speed rails, please mind that the wheels of your baby strollers are not caught by the door, and please mind the gap between the platform and the train.
 When the child's foot comes into contact with the floor or the wheel, stop using the stroller lest it be hurt.
Do not use in a lying angle if the child's head is beyond the backrest.

重要-使用前請詳細閱讀本說明書並妥善保存作日後參考之用

△ 警告(錯誤操作可能引致重大傷害或死亡)

不按照本使用說明書指引使用手推車,可能對幼兒造成重大傷害。 幼兒的安全是您的責任。

- 本產品適用於一個月初生兒至18kg的幼兒。
- 停止手推車時,請使用停車鎖。
- 不論有否承載嬰兒,停車時勿過分信賴停車鎖的性能。
- 即使已使用停車鎖,如載有嬰兒,應隨時留意手推車附近,以防任何危險發生。
- 切勿將小配件放近幼兒,以免幼兒吞下而造成窒息的危險。
- 為了防止幼兒窒息的危險,在拆開包裝後,請將塑膠袋之類的包裝物料丟棄。
- 過分超載,錯誤折疊以及使用未經認可的附件會對手推車造成損壞。
- 乘載幼兒時必須繫上安全帶,安全帶包含中央帶,腰帶和肩帶。前護欄不能防止幼兒從 座墊上站起來。請確認安全帶沒有鬆脫,以免幼兒突然跌出手推車。
- 為防止幼兒突如其來的動作令其跌出手推車,即使已經扣上安全帶,也請經常留意幼兒, 小心使用。
- 肩帶扣在插扣片上時,請勿交叉肩帶,以免肩帶對幼兒頸部造成壓迫。
- 請勿使用已破損的座墊,以免座墊不能發揮其應有功能,或令幼兒誤吞內裡的棉花等。
- 座墊起保護作用,推車未安裝座墊時禁止兒童使用,否則可能有造成傷害的風險。
- 當兒童乘坐時,看護人不要離開。
- 使用前一定要確認開關鎖已鎖上,否則手推車會有突然折起的危險。
- 不要讓幼兒操作前護欄以免其意外跌倒。
- 不可讓幼兒站立在車上,這是十分危險的。
- 切勿把身體靠於或把重物掛於把手上。
- 切勿懸掛物件 (康貝原廠的配件除外) 於車篷或把手上,以免引致手推車翻倒。
- 切勿承載超過一名幼兒,或讓幼兒坐在座椅以外的地方。
- 承載超重會容易產生不穩定的危險情況,產品最大承載重量:18kg,置物籃最大承載 重量:5kg。
- 禁止於樓梯間使用手推車。
- 不要讓幼兒操作手推車,以免手推車翻倒或發生其他意外。
- 開關手推車或調節座席靠背角度時要注意四周旁人及小孩,以免夾傷指頭。
- 開關或調節手推車時,請勿讓幼兒的手接觸活動零件部分。
- 對還未能坐直的幼兒,請勿使用直立角度,請以最平躺角度使用。新生兒建議使用最平 躺的角度。
- 推動手推車時請勿奔跑,應慢慢步行,以免轉向輪損壞,或引致翻倒等意外。
- 打開幼兒手推車時不要讓他人接觸,以免意外夾傷。
- 在座席使用的肩帶穿孔和座墊的肩帶穿孔位置要一致。如使用座席的上方肩帶穿孔,座 墊亦同樣要使用上方肩帶穿孔,不然肩帶有可能因長度不足繫緊幼兒。
- 一邊推行一邊調整座席角度是非常危險的,請勿同時進行。
- 推行時請注意路面狀況,不要讓手推車卡入排水溝蓋的縫隙中。
- · 孩子可能會滑落並導致窒息。當平躺時,請使用ASTM腳套。

重要-使用前請詳細閱讀本說明書並妥善保存作日後參考之用

企 警告(錯誤操作可能引致重大傷害或死亡)

- 不應在無人照顧下把嬰兒獨留於嬰兒車內,以免發生危險。
- 使用手推車前請確保推車所有鎖定裝置都已處於鎖定狀態,如安全帶長度調整,座墊扣 環扣上,推車已完全展開。
- 為了防止意外發生,孩子乘坐時必須繫上安全帶。
- 當靠背角度少於150度時,不適合6個月以下幼兒使用。
- 在把手上放置任何負載都會影響車輛的穩定性。
- 請一直將五點式安全帶扣上,以確保寶寶乘車時的安全。
- 此產品不宜於跑步或溜冰時使用。
- 請勿讓小孩玩耍本品。
- 為避免傷害,當產品在折疊和展開時,請確保你的孩子遠離產品。
- 使用時應遠離高溫、火源、水池或電源等鄰近範圍。
- 請勿使用未經製造商認可的附屬物。請勿使用非原廠供應的零件替換或自行改裝手推車。

⚠ 注意(錯誤操作可能引致受傷或元件損壞)


- 安裝座墊時,請確保所有帶扣等已經裝好,以免引致意外或造成損壞。
- 調整座席角度後,請重新調整安全帶至適當長度。
- 除開折手推車外,請勿觸碰開關掣。
- 當打開和收折推車時,請注意及避免可裝拆的座墊、手推車的安全帶、被子及玩具夾在 手推車車體上。
- 當越過不同段差時,若強行附加力量於前車輪上使之與段差碰撞,可能引起手推車損壞和故障,當越過段差時,即使是微小段差區的地方也應減緩推行,並踏上後腳支桿及往後按下把手往前行,確保前車輪越過段差才可通行。
- 當幼兒乘坐時,請勿在手扶梯上使用或搬動手推車。
- 使用者必須對本產品作定期保養。
- 每次使用前請檢查配件是否在運輸過程中被損壞。
- 請勿將手推車作承載幼兒以外的用途,否則會引致損壞。
- 請勿用力拉動、扭動、壓下前護欄,以免引致損壞。
- 假如放低椅背使用時座位太窄,可以將靠背調高一點使用。但注意幼兒應已差不多能獨 自坐直,才可這樣使用。
- 請勿讓成年人坐上手推車,或在上面放置重物,以免損壞手推車。
- 請避免連續長時間使用,特別是在夏天。
- 避免將手推車存放於高溫,接近熱源的地方或車廂內,因高溫可使手推車損壞或變形。
- 請定期檢查所有螺絲是否上緊。
- 有關火車上的使用:

本產品並非以火車上的使用為目的所設計的產品。假如閣下自行決定於火車上使用,請小心注意,並鎖上停車鎖,以免轉彎或刹車時令手推車翻倒。

- 請勿在提起手推車的狀態下按下開關掣,以免引致元件損壞。
- 收起手推車前請先確認置物籃內的物品已取出。
- 收折前請先確認車篷已經完全收起,以免引致組件損壞。
- 收起手推車時,請避免橫放,或於上面置放重物,以免車篷變形。
- 請勿手執開放的前護欄來拖動手推車。
- 即使已經鎖上停車鎖,手推車也有可能意外滑動或翻倒。
- 即使幼兒不在車上,也不可將手推車隨意放在路旁或斜坡等危險地方。
- 不可於斜坡、階梯、自動扶梯、顛簸坡道、沙灘、泥地等場所使用手推車。
- 推動手推車時請小心路上凹陷之地方,以免前輪意外陷進溝內令手推車翻倒。
- 如手推車出現損壞或操作問題,應立即停止使用,並將其存放在遠離幼童的地方。
- 請勿將本產品放近樓梯或梯級上。
- 如發現手推車損壞或有操作問題,請聯絡客服中心(或當地經銷商)。
- 只可在乾燥的平地上使用。請勿於雪地和強風時或濕滑路面上使用,以免令手推車或監護者意外翻倒。
- 請勿於打雷時使用手推車,以免意外遭受雷擊。
- 請勿外加任何以輪板或元件於主體上承載幼兒,以免發生意外或對手推車造成損壞。
- 請勿於公共汽車上使用手推車。

⚠ 注意(錯誤操作可能引致受傷或元件損壞)

- 跨越火車軌和汽車道的十字道口等時,請提高前輪跨越間隙,以免前輪意外卡在溝內引 致翻倒。
- 禁止連續長時間使用:連續長時間使用會對幼兒造成負擔。躺臥姿勢的連續使用時間上限為2小時,坐著姿勢的則為1小時。
- 感覺有異物卡住時,請勿強行折疊,以免造成損壞。應先打開手推車,確認後再操作。
- 收折前請將轉向輪翻往內側然後鎖定。如果不將轉向輪鎖定在內側位置,收折後手推車 將較易翻倒。
- 請勿承載太尖或太大的東西於置物籃中,以免置物籃損壞。
- 請定期清潔以及檢查手推車。請勿使用非中性的清潔劑清潔車架。
- 請注意勿讓油分附在幼兒有機會舔到的地方,如前護欄,扶手等。
- 如發現車輪外胎磨耗嚴重,影響推行,請聯繫客服中心(或當地經銷商)進行更換。
- 當放置和移開幼兒時請鎖定停車裝置。
- 為了手推車的穩定性,請勿將其他產品連接到推把、靠背的背部、手推車的側面等部位。
- 請牢牢繫上安全帶,但注意不要過緊。
- 切勿搬動承載了嬰孩的手推車,以免手推車突然收折。或手執前護欄等地方搬動手推車, 以免手推車意外滑脫或令前護欄鬆脫以致手推車掉下。
- 在乘坐如地鐵/高鐵等交通工具時,請注意手推車的車輪不要被車門夾住,並請留意站台和車之間的縫隙。
- 當幼兒的腳接觸到地面和車輪時,請勿使用手推車,有可能造成腳受傷。
- 假如幼兒頭部超出靠背前端時,請勿使用躺臥角度。



List of components

- 1. Handle
- 2. Adjustable button
- 3. Front guard buttons
- 4. Front guard
- 5. Front guard cover
- Carrying grip
- 7. Carrying grip cover
- 8. Basket
- 9. Foot rest
- 10. Front swivel wheel lock
- 11. Seat cushion
- 12. Headrest
- 13. Armrest
- 14. Front wheel stopper
- 15. Canopy snap
- 16. Seat reclining buckle

- 17. Seat cushion snap
- 18. Reclining belt
- 19. Back ventilation window
- 20. Safety lock
- 21. Folding lever
- 22. Canopy
- 23. Top window
- 24. Top window cover
- 25. Ventilation window
- 26. Shoulder belt cover
- 27. Shoulder belt
- 28. Shoulder belt insert outlet
- 29. Head support insert outlet
- 30. Waist belt insert outlet
- 31. Waist belt
- 32.Crotch belt cover

- 33. Crotch belt
- 34. Crotch buckle
- 35. Shoulder and waist belt buckle
- 36. Head support
- 37. EggShock pad
- 38. Body & Hip support
- 39. Handle lock
- 40. Open/Fold lock
- 41. Rear leg latches
- 42. Rear stay
- 43. Rear swivel wheel lock
- 44. Rear wheel stopper
- 45. ASTM foot cover(Only for packages that comply with ASTM safety standard. Taiwan version does not contain this accessory.)

部件清單

- 1. 把手
- 2. 調節掣
- 3. 護欄鬆脫掣
- 4. 前護欄
- 5. 護欄套
- 6. 輕便提帶
- 7. 輕便提帶套
- 8. 置物籃
- 9. 腳踏
- 10. 轉向輪鎖
- 11. 座墊
- 12. 護頭板
- 13. 扶手
- 14. 前輪停車鎖
- 15. 幌鈕釦
- 16. 角度調節釦


- 17. 座墊鈕釦
- 18. 角度調節帶
- 19. 背面透氣窗
- 20. 安全鎖
- 21. 開關掣
- 22. 車篷
- 23. 幌天窗
- 24. 天窗蓋
- 25. 透氣窗
- 26. 肩帶套
- 27. 肩帶
- 28. 肩帶穿孔
- 29. 護頭墊穿孔
- 30. 腰帶孔
- 31. 腰帶


- 32. 中央帶套
- 33. 中央帶
- 34. 中央帶釦
- 36. 護頭墊
- 37. EggShock 墊
- 38. 護背連臀墊
- 39. 把手鎖
- 40. 開關鎖
- 41. 後腳管活動鎖
- 42. 後腳支桿
- 43. 後輪轉向輪鎖
- 44. 後輪停車鎖
- 45. ASTM 腳套(僅符合美國 ASTM 安全基準的市場販 賣品配備。台灣無搭載此 配備)

Unfolding the stroller 打開手推車

The handle grip is returned to the straight position while pressing both adjustable button.

- X Handle grip is folded in sales package.
- 一邊按下左右推把調節掣,一邊轉動推把桿回到 直桿狀態。
- ※包裝時,推把呈折叠狀態。
- 1 Slide the safety lock as demonstrated direction and hold it in place.
- ② Grip and pull the folding lever upwards simultaneously.
- ③ Slightly lift the stroller and open it.
- 將把手上的安全鎖向箭頭方向滑動 並握住。
- ② 同時握著並提起開關掣。
- ③ 稍稍提起並打開手推車。






- WARNING: This product can only be opened or closed when the handle is at the back.


 Do not change the direction of the handle (release the lock) before unfolding the stroller. (in figure) The stroller may be damaged if the handle is not locked in the correct position.
- ♠ 告: 本產品只有在把手處于背面位置的狀態下才能開關手推車。打開手推車之前,請不要(解除把手鎖)操作把手換向(如图)。

把手沒有鎖定在正確的位置有可能會損壞手推車。




Using the swivel wheels 使用轉向輪


- 1 To use the swivel wheels Lift the swivel wheel locks (left and right) to release (according to the moving direction).
- 2 Swivel wheels not in use Press down the swivel wheel locks (the ones at the same direction of the user) to lock.
- WARNING: When you switched the normal use of handle, please make sure to raise the swivel wheel locks to release the locks. If you do not release the locks, there is a possibility that the wheels are not automatically switched. When reversing the handle, please release swivel locks (total 4 places). When the wheels are locked in the wrong direction, the stroller may damage to the parts while open.
- ① 使用轉向功能時,向上推起轉向輪鎖(左右)以解除。
- ② 不使用轉向功能時,請按下和推行者同壹方向的2處轉向輪鎖以鎖定。
- ♠ 告: 當您已切換至正常使用或正常把手,請務必將腳輪鎖提起解除腳輪。
 若不解除鎖定,這可能使腳輪不能自動轉換。轉換把手時,必須解除轉向輪鎖(共4處)。
 車輪被錯誤的方向鎖住時,打開手推車可能損壞零件。



Using the stopper 使用停車鎖


- To lock the wheels, press the stoppers down which are located at wheels on both left and right sides.
 Try to push the stroller back and forth slightly to ensure that the stoppers are properly engaged.
- (2) To release the stoppers, lift the stoppers to unlock.
- **WARNING:** Always engage the stoppers when you leave the stroller.
- ① 壓下左右車輪的停車鎖。 輕輕前後推動推車,確認停車鎖已鎖定。
- ② 將停車鎖往上撥即可解鎖。






Using the front guard 使用前護欄

- Open the front guard
 Press and hold the button at the end of the front guard as illustrated.
- 2 Attach the front guard Lift the front guard and plug into the projected part at the end of the armrest. Pull the guard to check whether it is securely locked.



- **WARNING**: Do not hold the front guard to lift the stroller while a child seated.
- 打開前護欄如箭頭所指按下前護欄鬆脫掣。抽起前護欄。
- ② 安裝前護欄 請先將前護欄提起對準插口,然後插入安裝。 用手拉一拉確認是否鎖定牢固。




♠ 告: 小孩乘坐時,請勿手執前護欄搬動手推車。

Detach the front guard cover 拆除前護欄套

Open the front guard and detach the cover from the front guard.

打開前護欄,從護欄上取下護欄套。



Adjusting the covering size of canopy 車篷大小的調節


- 1 Hold the canopy stay and pull the canopy forward for full coverage.
- 2 Hold the canopy stay and pull the canopy backward for reduced canopy coverage.


Note: The baby carriage can be directly folded if the canopy is in place. Be sure to fold the canopy when folding the stroller.

Opening with brute force may lead the canopy to be out of shape.

- ① 用手拉住車篷前支桿向前調節,即可展開車篷。
- ② 用手拉住車篷前支桿向後調節,即可收攏車篷。


小提示:在安裝了車篷的狀態下,也可以直接折疊嬰兒車。折疊嬰兒車時,請務必將車篷向後收攏折疊。 使用蠻力打開,可能會使車篷變形。





Using the top window and ventilation window 使用天窗和透氣窗

- 1 Open top window by releasing snaps.
- (2) Fasten the snap to close top window.
- ① 打開天窗須將鈕扣打開。
- ② 關閉天窗將車篷上的鈕扣重新扣上。



Using safety harness 使用安全帶

- ① Seat the child into the stroller and fit the shoulder belts on the child's left and right shoulder.
- ② Overlap the shoulder and waist buckles for left and right side separately.
- ③ Pull out the crotch belt and put the insert plastics into the buckle until a "Click" sound is heard.

Pull the shoulder belts and waist belts to check if it is secured.

4 Press the crotch buckle button to release the harness.

WARNING: Avoid serious injury from falling or sliding out, always use the restraint system.


Note: Adjust the length of seat belt properly after change of the backrest angle.


- ① 讓孩子坐在車內,使其肩膀左右與肩帶貼合。
- ② 分別將左右兩邊的肩帶扣與腰帶扣重疊。
- ③ 拿起肩腰帶扣左右插入中央帶扣,聽到"咔嚓"一聲,說明已安全插入。 拉動中央帶,腰帶,肩帶,確認有無鬆動。
- ④ 若要解開安全帶,按下中央帶扣中間的按鈕即可解除。




小提示:當改變靠背角度時,請謹記檢查並確認安全帶已作出最適當的調整。









Adjusting the waist/shoulder belt length 調節肩帶、腰帶的長度

- 1 Pull the waist belt end to direction A to shorten.
- ② Loose and pull out the waist belt to direction B, then pull it inward to extend the length to direction C.


Use the same method on waist belt to adjust the shoulder belt.


NOTE: Always leave at least 3cm at the belt end.

- ① 收緊時,將腰帶的前端位置往圖標箭頭A方向拉。
- ② 延長時,將腰帶表側往B箭頭方向鬆脫出來,然後再將腰帶向裡側往C 箭頭方向拉。

肩帶的調節方法同腰帶的調節方法一致。


小提示:注意腰帶末端應留下3cm以上的長度。





Attaching the insert plastics 將肩帶、腰帶裝到插扣片上

- ① Use the waist belt end to pass through from the buckle back slot ⓒ and slide out to slot ④.
- 2 Pull out the waist belt end from slot (B).
- ① © ② ® ③ © ④ 3cm above 3cm 以上
- ③ Slide out the waist belt end through slot ⓒ.
- 4 Pull out the waist belt from slot (A) and adjust the applicable length. (Leave 3cm or above)
- ① 將腰帶前端從穿孔 ⑥ 穿出再通過孔 ⑧ 拉出。
- ② 將腰帶前端通過穿孔 ⑧拉出。
- ③ 將腰帶前端再向穿孔 ② 通過。
- ④ 最後將腰帶向穿孔 A 拉出,並調至到合適的長度。(保留3cm以上)




Adjusting the crotch belt 調節中央帶時

Tightening - Pull the crotch belt to the direction (A). Extending - Follow the direction (B) and pull out the belt, then follow the direction (C) and pull the belt to the end.

收緊時,將中央帶朝著 (A)方向拉。

延長時,按照⑧方向拉出中央帶後順著◎方向拉到底。




Using the carrying grip 使用輕便提帶

Carrying grip is used for carrying the folded stroller.

Grab the carrying grip on the seat frame and put the handle under the arm as illustrated.

輕便提帶是用於攜帶收車後的嬰兒車。從折疊嬰兒車的把手,握著附設在座架上的手提帶子,將把手夾在腋下攜帶使用。








Reclining the backrest 調節靠背角度


- Recline Support the backrest with one hand then pull down the seat reclining buckle.
- ② Upright Pull the reclining belt by both hands at the same time.

NOTE: Raising the backrest may be difficult while a child is leaning on the backrest.

- ① 調低靠背角度時,先以單手支撐著小孩身 體,然後將角度調節釦往下拉調低靠背。
- ② 調高靠背角度時,將兩條角度調節帶往左右拉使角度調節釦往上即可。

小提示:幼兒靠在靠背時,角度調節會變得 困難。






Reversing handle 手推車換向

Lift and release the handle locks to change the handle direction until the locks are secured in places as show in figure.

如圖,將左右兩邊的把手鎖拉起解除後轉換把手方向,直至把手鎖重新鎖上為止。

MARNING: While using face-to-face mode, please make sure the stroller is fully opened before changing the direction of handle. Do not change the direction of the handle (release the lock) before unfolding the stroller. The stroller may be damaged if the handle is not locked in the correct position.




♠ 告 • 對面位置使用時,請務必在完全打開手推車后再切換把手的方向。

打開手推車之前,請不要(解除把手鎖)操作把手換向。把手沒有鎖定在正確的位置有 可能會損壞手推車。


Detaching the sun canopy 拆除車篷

- ①Release the snap(1places) of the canopy.
- 2Pull the hook at the lower end of the canopy joint forward with the finger tip, while pulling out the canopy joint from the canopy holder, and then remove the canopy as show in figure.
- ①解除車篷釦(1處)。
- ② 一邊將車篷接頭下端的卡釦用手指 尖往跟前拉,一邊從車篷固定架上 抽出車篷接頭,然后拆除車篷,如圖。



Attaching the sun canopy 安裝車篷

- 1) Switch the handle to face rear.
- 2 Recline the backrest to the lowest position.
- 3 Place the canopy facing the proper direction, fold the canopy.
- 4 Fully insert the canopy joint into the canopy holder.
- (5) Lift up the backrest and fasten the canopy snap.
- ① 將把手置於對面位置。
- ② 將靠背調至最低位置。③ 確認車篷前後方向,折疊車篷。④ 然後將車篷插桿插入車身上插座之中。⑤ 立起靠背,鎖定車篷紐釦。




Folding the stroller 收折手推車

Slide to release the safety lock of direction as illustrated.

Grip the folding lever and slightly lift up the handle, then press down the handle as illustration to fold the stroller.

MARNING: When folding the stroller, please ensure your child and other children are kept at a safe distance. Please ensure that they are not in contact with mounting parts and remove all items from the basket before folding the stroller.




如圖中箭頭方向拉動安全鎖作解除。

一邊握住開關掣,一邊提起把手,然後按下把手,推車被折疊起來。

Adjusting the handle angle 推把高度調節方法

- 1 Adjust the angle of handle grip by pressing both adjustable buttons.
- ② Release the adjustable button after selecting the appropriate angle.
 - *Please push it up and down slightly to make sure it is not loose after an appropriate angle is selected.
- ① 一邊按下左右兩邊的推把高度調節按鈕,一邊調節推桿的角度。
- ② 調節到合適角度時,鬆開推把高度調節按鈕。
 - ※ 推把高度調節後,請上下推動推把桿,確認是否有鬆動。




Basket 置物籃

The basket can carry a maximum weight of 5kgs. You can attach and remove it using the belts and snaps according to step 1, 2, 3 and 4.

- 1 Put the fastening belts ①,② into the safety hole on the left and right rod at the front of the stroller.
- 2 Put the fastening belts ③,④ into the safety hole on the left and right rod at the front of the stroller.
- 3 Roll the fastening belts ⑤,⑥ around the left and right rod at the back of the stroller. And then using the U-shaped buckles to lock it.
- 4 Put the fastening belts 7,8 into the safety hole on the left and right rod at the back of the stroller.

 After that, roll the velcro 9,0 around the rod at the back of the stroller




After all these steps are done, pulling the U-shaped buckle, fastening belt and velcro to see if it is secured.

置物籃的最大載重量是5kg。

使用安裝帶子及帶扣並按照步驟 ◆ 、 ◆ 、 ◆ 、 ◆ 安裝或拆除置物籃。

- 將位於籃筐前上方的2處固定帶①、②穿過前輪支桿左右的安全帶通孔並鎖定。
- 2 將位於監管前下方的2處固定帶③、④穿過前輪支桿左右的安全帶通孔並鎖定。
- ③ 將位於籃筐中間的2處固定帶⑤、⑥ 繞在車體後方的置物籃安裝架上,然後使用位於固定帶前端的U型釦鎖定。
- ④ 將籃筐後方的固定帶⑦、⑧穿過後輪支桿左右的安全帶通孔並鎖定。然後將籃筐後方的魔術貼⑨、⑩繞在後輪支桿上並鎖定。

通過拉拽確認U型釦、固定帶、魔術貼是否已牢靠。



Detaching the seat cushion 座墊的拆除方法


- 1 Press the crotch buckle release button and release the harnesses. Remove the crotch belt cover from crotch belt.
- (2) Remove the shoulder belt cover.
- ③ Release the snaps (2 places) on the inner side of the seat cushion.
- (4) Release the crotch belt from the seat cushion.
- (5) Release the left and right snaps which are secured to the base seat (2 places).
- 6 Detach the U-shaped buckles (2 places) fixed on the back tube above the base seat bottom.
- (7) Release the snaps of the side tube (2 places on each side).
- (8) Remove waist belt and shoulder belt and then remove seat cushion from base seat.


NOTE: To install seat go in the steps reverse.

WARNING: Make sure the seat cushion has been correctly attached before use.


- ①按下安全帶釦解除安全帶,從中央帶上拆下中央帶罩。
- ②取下肩帶套。
- ③ 從坐墊前端的固定釦帶(2處)上解開固定釦。
- ④ 從坐墊上拉出中央帶釦。
- ⑤ 解除坐墊釦在小坐席兩側的釦子(2處)。
- ⑥ 拆下鎖定在小坐席上方的靠背管材上的U形鎖釦(2處)。
- (7) 解除側面管和小坐席下部管的釦子(左右各2處)。
- ⑧ 將肩帶、腰帶抽出,然後將坐墊從底座取出。


小提示:若安裝請按照相反的步驟來操作。


















Adjust shoulder belt heights 調節肩帶高度

- 1 Pull out shoulder belt from seat cushion and base seat.
- (2) Insert the shoulder belt through the correct slots on the base seat.
- ③ Insert the shoulder belt through the correct slots on the seat cushion, make sure you use the slots in the same height.

NOTE: The lowest shoulder belt insert outlet should be used for children under 6 months.

- ① 先將肩帶從座墊及小坐席上解除。
- ② 將肩帶穿過小坐席上正確的肩帶孔。
- ③ 將肩帶穿過座墊上正確對應位置的穿孔,並確認兩邊穿孔在適當的高度。


小提示:當幼兒未滿六個月時,請使用最低的肩帶穿孔。



Using the carrying grip cover 使用輕便提帶套

Wrap the carrying grip cover around the carrying grip, then fasten the snaps (2 places) on the carrying grip cover.

將輕便提帶套包住輕便提帶,然後將輕便提帶 套上的釦子(2處)扣上。




The dacco cushion 懷抱型內墊

Correct position of head support

- The cushion pad of the head support should just touch at the child's neck.
- Installing the dacco cushion
- Put EggShock pad into pocket on seat cushion to use.

護頭墊的安裝位置

- 護頭墊部分應該剛剛抵幼兒頸部。 懷抱型座墊的安裝方法
- 將EggShock墊放入座墊上的口袋使用。




Installing the head support 護頭墊的安裝方法

Loop the head support belt through the head support hole, the belt is tipped opposite through the hole to attach. After it is installed, check if it is well secured to the seat cushion by slightly pulling. Reference for head support insertion outlets (A) (B)

Afor child from around 1 month to 4 months. For child from around 4 months to 7 months.

透過護頭墊穿孔通過頭部支援帶,將支援帶折迴繞過穿孔安裝。 它被安裝後,輕輕的拉動檢查它是否固定在可移動的座椅。 有關護頭墊穿孔 (A) (B) 的參考

- A大約供1個月至4個月的幼兒使用。
- B大約供4個月至7個月的幼兒使用。





Installing the Body& Hip support 護背連臀墊的安裝方法


- ① The both sides of waist belts pass through the upper holes of the body & hip support.
- ② Using the supporting belts (upper position) of the body & hip support to pass through the holes of the seat cushion body support location. To fix the supporting belts by opening the tail at the end.
- ③ Using the supporting belts (upper position) of the body & hip support to pass through the holes of the seat cushion hip support location. To fix the supporting belts by opening the tail at the end.

The crotch belt pass through the lower belt hole of the body & hip support.

- NARNING: Please STOP using the body and hip support which does not fit the child's body. To detach, please kindly follow the reverse steps.
- ① 請用護背連臀墊護背上的穿孔穿上腰帶;用護臀上的穿孔穿上中央帶。
- ② 將護背連臀墊護背上的支援帶穿過座椅上的身體支援帶穿孔。將支援帶折迴繞過穿孔安裝。
- ③ 將護背連臀墊護臀上的支援帶穿過座椅上的臀部支援帶穿孔。將支援帶折迴繞過穿孔安裝。










To use with EggShock pad 使用EggShock墊

- ① Store inside head support.

 The EggShock pad can be inserted into the
 - head support of Dacco Seat to protect child from the vibrations from the ground when strolling. Insert the EggShock pad from the rear packet of the head support.
- ② Store inside seat cushion to use. Insert the EggShock pad from the rear packet of the seat cushion.
- ① 放進護頭墊內使用時,EggShock墊可以 安裝到Dacco墊的頭墊內,在頭墊背部 的口袋進行安裝,用於保護幼兒頭部免 受推行時的震動影響。
- ② 放進座墊內使用時,將座墊頭靠背面的專用口袋打開放入EggShock墊。





Installing the ASTM foot cover 使用ASTM腳套

- 1. Press and hold the button at the left end of the front guard, put a band and foot cover onto the front guard as illustration.
- 2. Tie up another band to the projected part, plug the front guard into the projected part at the end of the armrest.
- 3. To attach front guard and fasten the holding strings to the base seat tubes to complete the installation.
- * This ASTM foot cover is only for packages that comply with ASTM safety standard.
- 手執前護欄末端如圖般按緊左邊的護欄按鈕, 將前護欄提起後慢慢將鬆緊帶和腳套穿到前 護欄上。
- 2. 然後將另一方的鬆緊帶固定在突起部分及將前護欄提起,向末端突起部分準確地按下。



- ※此ASTM腳套僅符合美國ASTM安全基準的市場販賣品配備。
- MARNING: Do not fix to the rear leg tubes as shown, as this may result in the stroller not being fully extended, causing unnecessary injury to children.
- ☆ 警告: 如圖,請勿固定在後腳管上,這可能導致嬰兒車不能完全展開,對小孩造成不必要的傷害。





Maintenance and Cleaning 保養和清潔

- Never apply force on any mechanism or moving parts.
- To prevent mildew forming, do not store this product in a wet or humid environment.
- · Avoid prolonged exposure of the product to rain or snow.
- Clean the plastic and metal parts with a wet cloth. For stubborn stains, use a diluted mild detergent.
- You may lubricate moving parts if the operation or movement of the stroller is not smooth. Do not apply excessive lubricant as it may stain with dust which may cause malfunction.
- Please do not apply any lubricating oil on open/fold lock, safety belt buckle, front guard plug, safety lock, folding lever and swiveling lock that will cause malfunction.
- 切勿強行拉動活動零件或裝置。
- 請勿將產品存放在潮濕的地方以免產品發霉。
- 避免將產品長時間暴露於雨水或雪霜之中。
- 請以濕布清潔金屬及塑膠部分。如遇頑固污垢,可使用稀釋的清潔劑。
- 若感到手推車操作或運行不順暢時,可以添加適量的潤滑劑。注意不要添加過多的潤滑劑, 否則反而會容易沾上灰塵,引起操作異常。
- 注意某些部位不可以加潤滑劑,如把手操作部、座席安全帶扣、前護欄的安裝部、開閉鎖周圍、轉向輪回轉部,否則可能引起操作不良。

Cleaning and maintaining fabrics 清洗和保養縫製品

- Be careful not to damage of the plastics on canopy and the snaps from basket.
- Due to the characteristic of the product, the color may fade after numbers of washing.
- It is recommended to wash with neutral detergent. Do not use detergent containing fluorescent brightener or bleach. This may cause chapped skin or a rash.
- Always keep clean due to the condition of storage, the mildew may be generated.
- 請注意不要損壞車篷的塑膠部分或籃子的U字鉤子等。
- 根據產品的特性,會有輕微的褪色。
- 洗滌的時候建議使用中性洗滌劑。請勿使用含螢光劑、漂白劑的洗滌劑,因為可能會引起皮膚乾燥、濕疹等。
- 請小心洗滌及保持清潔,同時需確保縫製品保管於通風環境,避免發霉狀況。

Washing of the seat cushion, front guard cover, shoulder belt, waist belt, crotch belt cover, shoulder belt cover, carrying grip cover

座墊、前護欄套、肩帶、腰帶、中央帶套、肩帶套、輕便手提帶套的洗滌方法。

- · Hand wash in warm water or machine-wash gently .
- When using the washing machine, put the laundries into the washing net before washing. Otherwise a fray and damage may cause.
- After washing, please twist it gently to make it dry. Hard twist may leave folds onto the fabric.
- Some sewing parts can discolor, so it is recommended to wash and spin separately with other clothes. Do not soak into the water.
- Rinse thoroughly, wring out lightly, and then arrange the shape and dry in the shade.
- Do not use drying machine, iron and dry cleaning.
- 請以溫水手洗或弱速機洗。
- 使用洗衣機的時候,請將縫製品放入柔洗袋內,避免縫製品損壞。
- 洗滌後,請輕輕地擰乾,大力擰乾的話可能會使縫製品留下褶皺。
- 部分縫製品可能會出現掉色,請跟其他物品分開清洗,另外請避免浸泡。
- 徹底清洗後,輕輕擰乾後,整理好形狀,放於陰涼處晾乾。
- 請勿使用烘乾機、熨斗及乾洗。

Washing of the seatback, canopy, basket, crotch belt 坐席、車篷、置物籃、中央帶的清洗方法

- Do not soak into the water. Use sponge or brush wipe off the dirt with warm water.
- After wipe off the dirt by detergent, use a cloth to wipe off the excess water and detergent.
- · Dry in shade area after wipe off water.
- 請勿將縫製品浸泡在液體中。請用海綿或毛刷並使用溫水來擦拭污垢。
- 當使用清潔劑擦拭後,請以幹布或海綿將多餘的水分或清潔劑抹淨。
- 擦拭後請置於陰涼處陰乾。

香港和東南亞地區消費者請參考下面:

Consumers from Hong Kong and South East Asia countries please refer to below:

供應商 Supplier:

香港九龍尖沙咀漢口道28號亞太中心1003室康貝香港有限公司

Combi Hong Kong Limited

Room 1003, HK Pacific Centre, 28 Hankow Road,

Tsimshatsui, Kowloon, Hong Kong.

Combi Corporation